



DIGITECH

User Manual

Digital Fridge/Freezer LCD Mini Thermometer

QM-6323




Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com

Specifications:

Temperature Display:	°C/°F Selectable
Digit height:	23mm
Temperature range:	-19°C to 49°C
Power:	1 x CR2025 (included)
Dimensions:	68(L) x 44(H) x 12(D) mm

Flyout:



- 1 Hanger
- 2 Temperature Sensor
- 3 On/Off Button
- 4 °C/°F Button
- 5 Magnet
- 6 Battery Compartment

Instructions:

- Pull out the battery compartment and remove the plastic film inside. Reinsert the battery compartment.
- Press the On/Off button.
- The display will show the current temperature.
- Press the °C/°F button to choose between Celsius or Fahrenheit.
- Use the hook, fold out stand, or magnet to mount.
- When mounted in a fridge, at the optimal temperature (4°C-8°C) a frost symbol ❄️ will appear. *Note: The temperature readout is -19°C-49°C.*
- When the battery symbol appears, please replace the battery.